RINKER 320 FIESTA VEE - 2006

Ref : CLBOI664536



Main datas

Builder : Rinker
Year : 2006
Length : 10,60
Draft : 1,00
hull : Monohull
Area : Spain Costa del sol
Berth details : PLACE DE 10M DISPONIBLE POUR 14.000? SUPP
Flag :

Subtype :
Architect :
Material : GRP
Beam : 3,50
keel : Fixed Keel
Life Raft : No
Mooring : Yes
Leasing in progress : No

Engines

Brand : VOLVO
Montage : In Board (IB)
Power Unit. (CV) : 270
Comments : Complete review by oficial Volvo mechanic 04/05/2017
Shaft : Z drive

Brand : VOLVO
Fuel : Diesel
Comments : Complete review by oficial Volvo mechanic 04/05/2017
Tank : 620

Shaft : Z drive

© Xboat 2024

Facilities

Sailor Cabin : 0
WC : Electric
Helm : No
Double Cabin : 2
Head : 1
Flybridge : No

Electronics

Radar details :
Sounder details :
Plotter details :
Watermaker details :
Radar : Yes
Autopilot : Yes
GPS : Yes
VHF : Yes
Watermaker : No

Bridge equipment

Hydrolic Gangway : No
Bath platform : Yes
Winter cover : No
Furling mainsail : No
Sails details :
Teak cockpit : No
Gangway : No
Davits : No
Electric windlass : Yes
Furling genoa : No
Spinnaker : No
Teak deck : No

Major equipment

Stern thruster : No
Group and thruster details : Kholer 220v
Charger and AC details :
Tender : No
Details :
Bow Thruster : No
Marine Gen. : Yes
AC : Yes
Flaps : No
Tender Engine : No

© Xboat 2024

Appliances

Freezer : Yes
Microwaves : Yes
Oven : No
Heating details : Avec la clim
Heater : Yes
TV : Yes
TV antenna : No
SAT-TV : No

IceMaker : No
Oven : No
Electric stove : No
SAT-TV : No

Divers

Comments : Great open boat
With every extras
not a lot of engine hours
Spot in port available

© Xboat 2024

Médias



 © Xboat 2024



© Xboat 2024



 © Xboat 2024



 © Xboat 2024



 © Xboat 2024



 © Xboat 2024



 © Xboat 2024



 © Xboat 2024



 © Xboat 2024



 © Xboat 2024



 © Xboat 2024



 © Xboat 2024



 © Xboat 2024



© Xboat 2024



 © Xboat 2024



 © Xboat 2024


MAIN
AIR CONDITIONER
WARNING
GASOLINE VAPORS CAN EXPLODE
RESULTING IN INJURY OR DEATH.
BEFORE STARTING ENGINE:
- CHECK ENGINE COMPARTMENT
FOR GASOLINE OR VAPORS.
- OPERATE BLOWER FOR 4 MINUTES
AND VERIFY BLOWER OPERATION.
- RUN BLOWER AT SLOW SPEED.
BLOWER
START
STOP
GENERATOR
SHORE POWER
REVERSE
POLARITY
MAIN
DO NOT
REMOVE
AIR CONDITIONER
REVERSE
POLARITY
SensaTank II
©Xboat

 © Xboat 2024



© Xboat 2024



© Xboat 2024



 © Xboat 2024



 © Xboat 2024



© Xboat 2024



 © Xboat 2024